

SLIMLINE ESCUTCHEON

INSTALLATION INSTRUCTIONS

1. INSERT THE RUBBER O’RING # 2 INTO THE SLIMLINE WALL FITTING # 1.
2. PLACE THE SLIMLINE EYEBALL # 3 ON TOP OF THE O’RING # 2.
3. PLACE THE POLY SPACER # 4 ON TOP OF THE EYEBALL # 3.
4. CENTER THE SLIMLINE ESCUTCHEON PLATE # 5 OVER THE FACE OF THE SLIMLINE WALL FITTING # 1, AND TIGHTEN UNTIL SNUG.

CAUTION: DO NOT USE ABRASIVE OR CAUSTIC CLEANSERS ON DECORATIVE ESCUTCHEONS AS THEY WILL DAMAGE THE FINISH AND VOID THE WARRANTY.

DIAGRAM:

